
D235 / LC Lounge | Help Sheet

Instructions on how to use the **D235** / **LC Lounge** instructional cart's computer, a/v & video conferencing equipment, connected cables, etc.

Cart's Lock Cabinet

Please borrow a key from Multimedia to unlock the cart's storage cabinet to access the **flatscreen TV remote**, **USB Mic** and **Web Cam**



1 Flatscreen TV (NEC 55" V552 LED Monitor)


Flatscreen:


The **flatscreen tv** is installed on the LC Lounge's west side wall

To turn on the flatscreen tv, press the POWER ON button on the remote

To turn off the flatscreen tv, press the STANDBY button on the remote

- Please remember to **turn off** the **flatscreen tv** after your presentation
- It's best to point the remote at the **flatscreen tv** closely & directly when turning it **ON/OFF** (please note, there is a slight delay when the monitor is turning on)
- If needed, press the remote's **HDMI** button to select/connect the tv to the Mac mini via **HDMI** cable 2





2 Speakers | Logitech Computer Speakers

Speakers: When the Logitech Speakers are turned off the POWER LED Indicator is blank

- To **turn on** the **Logitech Speakers**, turn the **POWER/VOLUME** dial on the right speaker all of the way clockwise (the **LED Indicator** turns **on**) and set them to the desired volume
- Please note, the **Logitech Speakers** are powered via a **Power Adapter** & connects to the **Mac mini's External Headphone output** via the speakers **1/8" stereo mini audio cable**




POWER/VOLUME dial

Turn the **POWER/VOLUME dial** all of way clockwise to **turn on** the speakers and set them to the desired volume Please note that because the sound is output from the **Mac mini (External Headphones)**, you can also adjust the volume with the computer's **sound controls** (see below)

Sound:


Use the **sound controls** on the **keyboard** or in the **Menu Bar** to adjust the **Mac mini's** output volume level to the **Logitech Computer Speakers**



3 System Settings | Mac mini (computer)

Check: VIDEO: € > System Settings > Display > VA2747 100Hz (Mirror/Optimize for VA2747)

Menu Bar: ☐ Screen Mirroring > Mirror to > VA2747 100Hz (Mirror/Optimize for VA2747) →



Screen Mirroring

Mirror or Extend to:

VA2747 100Hz

Currently Mirroring


6

Princy Controll


And Controlled to the Con

SOUND: System Settings > Sound > Output > External Headphones

*Scroll down/past this group of functions in the sidebar to find/select SOUND



INTERNET: **€** > System Settings > Network > Ethernet (Connected)




4 Cable Connections

Make sure: • the Mac mini is turned on (press Power button if it's turned off)

HDMI cable 1 is firmly attached to the HDMI port on the Mac mini

the **Multiport adapter** is firmly attached to the **Thunderbolt / USB 4 port** on the Mac mini


HDMI cable 2 is firmly attached to the HDMI port on the USB-C to HDMI adapter




Video Conferencing | Equipment & Software

The **Logitech Web Cam** & **Phoenix Quattro3 USB Mic** is equipment to assist in streamlining collaboration for online classes, presentations, and meetings.

They both connect to the computer's USB Hub (installed on the monitor stand) via USB-A cables.




Phoenix:
Quattro3
USB Mic



Cables: The cable connections for the Logitech Web Cam & Phoenix USB Mic are as follows

The Logitech Web Cam & Phoenix USB Mic both connect to the Mac mini's (computer) USB Hub via USB-A cables



Virtual: Meetings

- Using the Logitech Web Cam & Phoenix Quattro3 Mic for Teams video conference meetings
 - Connect the Web Cam and USB Mic to the External USB Hub
 & Launch your Teams meeting by clicking Meet Now
 - Choose the following video & audio settings in your Teams meeting in conjunction with LC-06's Web Cam, USB Mic and Flatscreen TV Speaker
 - Video/Camera: HD Pro Webcam C920 | Mic: Phnx Quattro3
 Speaker: External Headphones (Built-in)

